



November 25, 2025

## Driver Setting Procedures

Driver Setting Procedures for SOULNOTE D-1/D-1N/D-2/S-3/S-3ver.2/S-3 Reference/D-3/Z-3/B-3

Drivers : This software is used to connect the D-1/D-1N/D-2/S-3/S-3ver.2/S-3 Reference /D-3/Z-3/B-3 (Hereinafter referred to as the "USB input device") to a computer. Use it after installing the driver on your computer.

- Drivers must be installed for Windows OS.

## Installing Drivers (Windows)

### <Items to prepare>

- SOULNOTE USB input device
- A Windows computer (Windows10(64bit) or later)
- USB cable
- Driver: soulnote\_usb\_audio\_driver\_win.zip

Download the software from

[https://www.kcsr.co.jp/eu\\_sn\\_software.html](https://www.kcsr.co.jp/eu_sn_software.html) (Europe)

[https://www.kcsr.co.jp/us\\_sn\\_software.html](https://www.kcsr.co.jp/us_sn_software.html) (USA)

[https://www.kcsr.co.jp/asia\\_sn\\_software.html](https://www.kcsr.co.jp/asia_sn_software.html) (Asia)

and save it to the proper location on your computer.

### <Installing the driver>

- \* Start with the USB input device not connected to the computer.
- \* Please uninstall any old versions before installing the new one. ([Uninstalling: Page 6](#))

#### ① Right click the downloaded file

soulnote\_usb\_audio\_driver\_win.zip and select “Extract all” to extract the folder. (\* Operational errors will occur if you select “run” in the compressed folder without first selecting “Extract all”.) Click on SOULNOTE USB Audio Setup.exe in the extracted folder to run the program.

\* If a message appears saying “Windows Protected Your

PC” , click “More info” and then click “Run” on the next screen.

Select English in the “Select Setup Language” menu and click “Next” .



② Click “Install” on the “Welcome to the SOULNOTE USB Audio Software InstallShield Wizard” screen.




③ The following screen will appear after installation is complete. Click “Finish” .



## [Uninstalling drivers (Windows)]

- ① Click “Settings”  in the Start Menu to open the Windows Settings window.
- ② Click “Apps” to open Apps & features.
- ③ Click “SOULNOTE USB Audio Software” from the list of items.



- ④ Click the “Uninstall” button to uninstall.

